







































USER MANUAL

AD-D-DD1-1600L-02-B

anda seat



ACCESSORIES LIST

A  x2	B  x2	C  x1	D  x1	E  x1
F  x2	G  x2	H  x2	I  x4	J  x2
K  x1	L  R x2	M  x1	N  x1	O  x2
P  x1	Q  x1	S  x2	T  x2	U  x1
W  x2	V  x4			
①  M6×12 x24	②  M4×30 x2	③  M4 x2	④  x1	⑤  M6×30 x2
⑥  M6 x2	⑦  M8×25 x8	⑧  M4×14 x70	⑨  M5 x1	⑩  x1
⑪  x5	⑫  x4	⑬  x1	⑭  M6×40 x16	

ASSEMBLE GUIDE

