

FOR THE WINNERS' CIRCLE.



PHANTOM 4

USER MANUAL



PACKAGE CONTENTS

- 1X Backrest
- 1X Seatbase
- 1X Wheel Base
- 2X Armrests
- 1X Neck Pillow
- 1X Full-tilt Mechanism
- 2X Magnetic Side Covers
- 5X Casters (Wheels)
- 12X M8 Screws (2pcs Spare Screws)
- 1X Long Allen Key
- 1X Gas Piston+Sleeve
- 1X Safety Cap

ASSEMBLY GUIDE


1. Install Wheels

Insert 5 casters into the socket brackets.



2. Install Piston and Piston Sleeve

Insert the gas piston and slide the sleeve over piston.



3. Install Armrests

Screw on the armrests with 8 screws into the holes on the back of the cushion (Distinguish the left and right armrests).



4. Unscrew Backrest

Remove the 4 units pre-installed M8 screws on the backrest.



5. Connect Backrest Right Side

Slide the right side backrest bracket down onto the right recline bracket. Insert M8 screws previously removed from the backrest and screw them in halfway.



6. Connect Backrest Left Side

Push the left recline bracket up to align with the screw holes on the left of the backrest. Insert the M8 screws, then tighten all 4 fully on both sides of the backrest using the Allen key provided.



7. Install Side Covers

Align the magnetic side covers on top the brackets of backrest and they will snap magnetically in place.
Notice: the one with a gap is the right side cover.



8. Remove Notice Strap and Safety Screw

Remove the notice strap, then take off the red screw on right recline side by hand. This allows the recline to be used.



9.Insert the Safety Cap

Cover the safety cap on this hole. This safety cap can be removed with the red screw to push it from the inside.



10.Set the Chair Facing Down

Gently lift the chair and set it facing downwards.




11. Insert Levers

Line up the grooves inside each lever with the notches and insert fully into the shaft.
Reminder:Be sure to match the "Front" label. If not, the chair may lean forward and need to be reassembled.



12. Attach Tilt Mechanism

Attach the tilt mechanism to the bottom of the seat base with 4 units of M8 screws. Make sure the correct FRONT direction. Insert the screws in half and tighten fully after them in place.



13.Connect Base with Chair

Lift the assembled wheelbase and insert the piston into the socket of the tilt mechanism.



14.Put the Chair UP

Carefully tilt the chair into an upright position while holding the wheelbase.



15. Install the Neck Pillow

Fix the neck pillow on the top of chair through the elastic straps and buckle. Put the magnetic pillow on the back like image.



Congratulations! Your Anda Seat Gaming Chair has been fully assembled.

FUNCTION GUIDE


Backrest Recline

First fully pull up and hold the tilt lever, then lean back slowly until the backrest reaches to your desired angle, then slowly release the tilt lever back to its original position and lock it.



Armrests Adjustment

Up&down: Press and hold the lever to move the armrest up and down.
Hold armrests firmly to:
Move up or down to the ideal height.
Slide forward or backward.
Rotate the upper pivot 360°.



Tilt Tension

Turn the knob clockwise to loosen the rocking tension, anti-clockwise to tighten. Adjust it according to your weight and do not attempt to turn it past its maximum or minimum points.



Armrest Width Adjustment


Loosen the M8 screws at the bottom of armrests. Move the armrests to the desired position then tighten to secure.



Mechanism

Height Adjustment: Pull the right lever up to adjust the height of the chair.
Tilt Lock & Unlock: Push the right lever in to tilt lock, pull it out to unlock the tilt angle.

Right Lever (While Seated): Pull the right lever up to adjust the height of the chair.
Left Lever (While Seated): Push down to lock the tilt mechanism, pull up to unlock.



Pop-out Lumbar Support

Raise Pop-out Support: Simply press the lumbar support pad to pop out. Stop it at any angles to conform to your back.
Adaptive Movements: The pad effortlessly rotates left-right and pivots up-down to maintain optimal contact with your lower back during movement.
Lower Pop-out Support: Push the lumbar support upward to its highest position to disable it. Lower the pad to the lowest position.



SAFETY INSTRUCTION

Recommended Size

Chair Size	L
Recommended Weight	<100kg(<220lbs)
Recommended Height	<185cm(<6'1")

Precautions

- 1.Do not use chair for other purposes other than originally intended by the manufacturer.
- 2.Do not use the chair as a ladder.
- 3.We recommend to place chair on soft coverings when used on hard floor to avoid damage.
- 4.Chair is designed for flat surface use.
- 5.Chair is designed for single person use.
- 6.We recommend not to move the chair with objects on it.
- 7.Do not place the chair near flammables for the risk of fire hazard.
- 8.Avoid long time direct sunlight.
- 9.Keep away from fire or water hazards.
- 10.Use a soft dry cloth for general cleaning and maintenance of the chair. Do not apply corrosive chemicals on the chair.
- 11.Do not dismantle parts outside of original installation procedures.



Sit in the center of the chair.



Do not stand on the chair.



Do not use the chair with more than one person.



Do not use rocking mode over weight limit.



Do not push the chair around when a person is sitting in it.



Do not push down on the backrest when a person is reclined.



Do not place all your weight on the backrest only.



Do not place your hand or fingers near the recline mechanism.

The chair should only be used as intended and in non-abusive manner.
For warranty information, please visit <https://www.andaseat.com/pages/warranty>
Have any question or need any assistance, please contact: sales-support@andaseat.com